

Thank you for choosing the PureQ 778 Instant Read Thermometer!

Please take a few minutes to read the instruction before first use.

Features:

- IP67 Waterproof design
- Can be re-calibrated in °C or °F (To 0°C or 32°F)
- Min/Max temperature record.
- Display resolution: 0.1°C.
- °F/°C switchable using a push button.
- Measurement range: -50°C-300°C (-58°F-572°F). 
- Measurement accuracy: ±1°C(±2°F) at -20°C-150°C (-4°F-302°F)
- ±2°C (±4°C) at 150°C-200°C (302°F-392°F), over 2°C (4°F) at the other ranges.
- Large Bright Backlit light can be turned on and off, also can be auto-off in 30 seconds 
- A strong internal magnet allows the thermometer to be able to attach to a fridge or steel surface steadily
- Hold temperature function to stop the display from changing the readout.
- Built in bottle opener for the ultimate convenience while you're tending to the que
- Probe rotates 235 degrees and making the device convenient for both right-hand and left-hand users
- LCD viewing angle rotates automatically like a smartphone according to different grip.
- PureQ 778 automatically turns off after 10 minutes of inactivity, preserving battery life.

**Operation:**

1. Before using the thermometer, please peel-off the protected film from the front panel.
2. To start the measurement, unfold the probe from its housing and the LCD will immediately display the temperature.
3. The **default display units are Fahrenheit**. If you are willing to change it to Celsius, please press down the C/F key for 3 seconds
4. Data-hold: Before withdrawing from food, press "HOLD" key. This will hold the temperature reading until pressed again.
5. To display the minimum or the maximum temperature, push the "MAX/MIN" key. It will firstly display the saved maximum temperature. By clicking it again, the display will show the minimum saved temperature.
6. To enable light on the screen, press the light button. When the backlit light is on, press light button to turn off. Alternatively, the light will turn off automatically after 30 seconds

To calibrate the temperature:

1. Fill a glass with ice, then cover with cold water.
2. Wait 5 minutes to fully cool water
3. Insert the probe into ice-water, ensure the probe tip touches the ice (under water)
4. Hold for 3 seconds then hold down the 'CAL' key for 3 seconds.
  1. After 3 seconds, the display will show "CAL" on the screen.
  2. Use the C/F key to increase the digit or the "MAX/MIN" key to decrease the digit until you reach 0°C or 32°F.
  3. Press the "CAL" to confirm the calibration.

### Warnings and precautions!

Do not leave the Thermometer in the oven while cooking.

Do not touch the bare metal probe after inserting in meat – It may burn you.

Wash the metal probe in soapy water. Clean the thermometer by hand using water. Do not completely submerge the digital thermometer in water for extended periods.

Sterilize the metal probe by inserting it into a boiling water for several minutes.